

## Installation Instructions

1. Cut threshold to the required size.
2. Notch around door frame, if desired.
3. Attach threshold with fasteners provided.
4. For moisture control, caulk around base of threshold.

400S, 401S, 402S, 403S, 404S, 406S, 407S, 408S, 410S, 411S, 412S, 413S, 414S, 415S, 416S, 417S, 418S, 419S, 420S, 421S, 422S, 423S, 424S, 426S, 427S, 428S, 430S, 431S, 432S, 433S, 434S, 435S, 436S, 438S, 440S, 442S, 443S, 444S, 445S, 450S, 451S, 452S, 455S, 460S, 465S, 477S, 478S, 481S, 484S, 492S, 503S, 504S, 505S, 506S, 515S, 516S, 517S, 518S, 520S, 532S, 541S, 552S, 560S, 565S, 570S, 572S, 575S, 580S, 599S, 600S, 701S



**POSITIVE PRESSURE TESTED GASKETING MATERIALS FOR FIRE DOORS  
FOR APPLICATION TO HOLLOW-METAL-TYPE FIRE DOORS  
RATED UP TO 3 HOURS, WOOD AND PLASTIC COVERED  
COMPOSITE-TYPE FIRE DOORS  
RATED UP TO 1-1/2 HOURS AND WOOD CORE DOORS  
RATED UP TO 20M  
CATEGORY J  
<28X8>**

484S



**GASKETING MATERIALS FOR FIRE DOORS  
FOR APPLICATION TO HOLLOW-METAL-TYPE FIRE DOORS  
RATED UP TO 3 HOURS, WOOD AND PLASTIC COVERED  
COMPOSITE-TYPE FIRE DOORS  
RATED UP TO 1-1/2 HOURS  
<28X8>**