

734 Fire & Smoke Seal Installation Instructions I-TW00015 6500-8027 Rev. 4, 01.27.17

Sizes: 7' (2.1 m)		
Finishes: Black Brown Tan White	Manufa	ctured-On Date
This product must be installed to allow the proper opening and closing of the door assembly with a minimal amount of force. The door assembly should be checked periodically to ensure proper operation. TOOLS REQUIRED • Tape measure • Knife or scissors	JAMB LATCH	AD SIDE III
1/8"	JAMB DO	SIDE SIDE

This product has been designed to provide an effective fire and smoke seal in the gap around a fire-rated door and/or at the meeting stile between a pair of fire-rated doors. 734 Fire & Smoke Seal is to be installed as illustrated above, around the perimeter and/or at the meeting stile of the door assembly.

Care should be taken to install this product without stretching or damaging it in any way. The temperature of the frame should be above 40° F. The frame should be thoroughly cleaned removing dust, oil, grease, or dirt. Certain paint products may make adhesion difficult. If necessary, lightly sand the painted surface and then thoroughly clean. Secure adhesion is crucial to the proper performance of this product.

- 1. Measure the frame at the top and both sides.
- 2. Cut the product to fit using a knife or scissors.
- 3. Remove protective backing one foot at a time.
- 4. Adhere seal to the exact location on frame where section is to be installed. Do not remove and relocate.
- 5. Inspect seal to ensure proper adhesion.
- 6. Do not install this product to impede the opening and closing of the door assembly. The door assembly must operate effectively.



POSITIVE PRESSURE TESTED GASKETING MATERIALS FOR FIRE DOORS
FOR APPLICATION TO CATEGORY B HOLLOW-METAL-TYPE FIRE DOORS RATED UP TO 3
HOURS, WOOD AND PLASTIC COVERED
COMPOSITE-TYPE FIRE DOORS RATED UP TO 1-1/2 HOURS
CATEGORY G, H & J
<73NN>