



Installation Instructions

1. If using an auto door bottom remove the middle knock out to allow plunger to contact jamb.
2. remove backing from adhesive
3. position at corner of jamb and floor (see illustration)
4. attach to surfaces by pressing firmly around pad.

