

42KE Installation Instructions

- 1) Prepare door
 - a. Transfer horizontal and backset centerlines from exit device side of door to trim side.
 - b. Mark hole locations based on below dimensions.
- 2) Drill holes per drawing below.
- 3) Insert trim and mount to mounting plate with 2 M4x25mm PPhMS screws.

